Your First Choice for Specialty Metals

## M2 - Technical Data

## **General Descriptions:**

M2 is the most popular grade of high speed steel and is commonly used in a wide variety of cutting tools and metal forming applications.


M2 has a good balance of toughness, wear resistance and red hardness, which makes it well suited for a variety of applications.

#### **Example of applications:**

Drills, end mills, tool bits, broaches, milling cutters, form tools, taps and punches. M2 can also be used in numerous cold work applications as well as certain hot work applications.

Chemical Composition						
Carbon	Molybdenum	Tungsten	Vanadium	Chromium	Silicon	Manganese
0.78%-0.88%	4.50% - 5.50%	5.50%-6.75%	1.75% - 2.20%	3.75% - 4.50%	0.20%-0.45%	0.15%-0.40%

Comparison Chart	■ Toughness	Red Hardness	■ Wear Resistance



Typical Heat Treat Response					
Tempering Temp	Hard	Hardness (HRC)			
°F	2100°F	2150°F	2250°F		
975	64	65	66		
1000	64	65.2	66.8		
1025	63.5	65.1	66.8		
1050	62.6	64.8	66		
1075	61.3	64	65		
1100	60	62.5	64		
1125	58.4	60.5	62.4		
1150	57	58	60.9		
1175			59		
1200			57		

Size Changes During Hardening				
Hardening Temp °F	Tempering Temp	HRC	Longitudinal Size Change %	
2200	1025	65	+0.22	

#### **Surface Treatment**

M2 can be nitrided, or titanium-nitride coated. If it is titanium-nitride coated, care is required in vacuum hardening.

# M2 - Technical Data

## **Heat Treatment**

### **Forging**

Critical temperature - 1530 °F.

Forging temperature - 2075 °F. Slow cool after forging. Do not forge below 1700 °F.

#### **Annealing**

Heat to 1600 °F and hold for two hours at temperature.

Slow cool 25 °F per hour to 1000 °F, then air or furnace cool to room temperature.

Resulting hardness - Brinell 217/255.

#### **Stress Relieving**

Performed after rough machining to minimize distortion in heat treatment.

# 1200 °F, hold for two hours at temperature, then air cool to room temperature.

### Hardening

Salt bath or vacuum furnace preferred.

## High Heat (Austenitizing)

Preheat-1500/1550 °F - let parts equalize. 2100/2225 °F - soak for 5-10 minutes. For vacuum hardening, use the high side of the austenitizing range and use longer soak time.

## Quench

Salt bath quench to 1000/1100 °F, equalize, then air cool to 150 °F. Temper immediately following the quench.

. Vacuum quench at a minimum of 50 °F per minute down to below1000 °F, then cool to room temperature.

## **Tempering**

Minimum of 1000 °F tempering temperature required.

Double tempering is required, triple tempering is recommended.

Air cool to room temperature between tempers.

## **Physical Properties**

Modulus of Elasticity	30 psi x 10 <sup>6</sup> (207 GPa)	Density	0.294 lb/in <sup>3</sup>
Annealed Hardness	215-255 Brinell hardness (BHN)	Machinability	Similar to D2.